AcTIVEJ»ro
SPORT WATCH

12 Characters Electronic Watch Instruction Manual

A.Features:

- 10 Digits LCD Display.Display Hour,Minute,Second,Month,Day and Week
- 12/24H format selectable.Auto Calendar.
- 1/100 second Chronograph with split functions.
- Daily Alarm and Chime hourly
- EL backlight

B.Operational Manual:

◆ Press B key to convert MODE:



At any mode,press C key the ELback light on for 3 seconds.

C.Alarm functions:

- In normal mode.press B key once to enter Alarm mode,then press A to ON/OFF "ALM '{} "/"SIG . "function.
- In normal mode.press B key once to enter Alam mode, then press D key once,"Hour"flashing,press D key once again, "Minute"flashing,press A key, can adjust "Hour" and "Minute" respectively,press B key to normal mode.

D.Chronograph functions:

+In normal mode press B key twice Chronograph, Press A to start, Press A again to stop, Press D to zero, Press B to normal model

i

to setting mode and the "Seconds"flashing,press D key, "Hour","Minute", "Month","Date","Week" Flashing successively.Press C key can adjust:Time,Minute,Month,Date,Week.Press B key to normal mode.

+Press B to the clock mode.

I.Pull-out crown to stop the second hands stop.

2. Rotate crown to settle time.
3. After settle the time.push the crown firmly to the normal location.

This watch is Splash Resistant only.
Never push button in the water.